



Shoreline Wave™ V4 PCR Amplify Protocol

Sets A, B, and C (96 Samples)

Prepare amplicons for sequencing using single-step PCR amplification of the of the 254-base pair V4 region of the 16S rRNA gene for microbial community profiling up to 288 samples. This kit is one of three that contain unique barcoded primer sets for processing 96 samples, each primer has the structure: **<TruSeq Universal Adapter: Part A><8 base barcode><TruSeq Universal Adapter Part B><16S specific primer>**. Every sample will have a unique barcode at the completion of the PCR reaction for sequencing all the samples together.

Products

Up to 288 different samples can be barcoded and combined in a single sequencing run using the three available kits.

1. Shoreline Wave™ V4 PCR Amplify Set A (96 Wells) Cat. No. **WAVEV4-A**
2. Shoreline Wave™ V4 PCR Amplify Set B (96 Wells) Cat. No. **WAVEV4-B**
3. Shoreline Wave™ V4 PCR Amplify Set C (96 Wells) Cat. No. **WAVEV4-C**

Additional Items Needed for 96 Barcode Kits: (Not included; see Suggested Supplier list below)

1. Additional Items Required for Amplify:
 - a. Qiagen MinElute® PCR Purification Kit
 - b. Sterile Laboratory Grade Water
 - c. Sterile 100% Ethanol
2. Suggested items for sample QC
 - a. 0.8% agarose gel with ethidium bromide or other dsDNA stain
 - b. Gel loading dye to mix with samples (e.g., NEB B7024)
 - c. 2kb DNA ladder

Kit Contents for Shoreline Wave™ PCR Amplify Protocol

1. 96-well PCR plate with 96 barcoded primers in wells A1-H12
2. 2X PCR Premix (**blue cap**)
3. PCR sealing film (1 sheet)

Shoreline Wave™ PCR Amplify Protocol

1. Remove the plate seal from the Amplicon Primer plate.
2. **Add 10 µL 2X PCR Premix (**blue cap**)** to each position in the 96-well plate. (Use a Repeater pipette.)
3. **Add 10 ng – 100 ng Purified genomic DNA** to each of the 96-wells.
4. **Adjust remaining volume with water so that the PCR reaction final volume is 20 µL**
5. Using the PCR sealing film provided with the kit, cover the plate and seal tightly with no gaps.
6. Primers will dissolve off the bottom of each well. Observe that blue color is uniformly distributed throughout **20 µL reaction**, if not, tap plate gently until uniform blue color is achieved in each well.
7. Spin plate briefly if reaction mix is not completely at the bottom of the wells.
8. Transfer the plate to PCR machine; close and lock the lid. Run PCR protocol:



Shoreline Wave™ V4 PCR Amplify Protocol
Sets A, B, and C (96 Samples)

95°C, 3:00 Denaturation
Repeat 34X { 95°C, 0:20
58°C for 0:15 (**Ramp speed 4°C/sec**)
72°C, 0:15
72°C, 2:00 Final extension

9. Check reactions on gel: Run 1.5 µL of sample with 5 µL diluted gel loading dye on 0.8% agarose gel in TBE, 150V for approximately 45 minutes, with DNA ladder. Band should be present at ~ 450bp.

Qiagen MinElute® PCR Purification Protocol

1. Follow MinElute instructions for adding Ethanol (96% - 100%) to PE buffer, and label tubes.
2. Pool 5 µL of each amplified sample from the 96-well plate (*when pooling 96-sample well plate and 16-sample tubes, pool 5 µL of each amplified sample from all plates/tubes*) into a clean 1.5 mL microcentrifuge tube. (**Save 2 µL of pooled unpurified DNA for gel comparison with purified DNA in the last step below**)
3. Combine **80 µL** of pooled sample with 400 µL of Qiagen PB buffer.
4. Transfer **all** the resulting solution into the MinElute column with provided 2 mL collection tube.
5. Centrifuge the MinElute column at 17,900 RCF for 1 minute or until solution has passed through the column. Discard the flow-through in the collection tube and return the column into the empty tube.
6. Add 750 µL Buffer PE to the MinElute column and centrifuge at 17,900 RCF for 1 minute; discard flow through and return MinElute column to the collection tube. Centrifuge for 1 minute at 17,900 RCF to remove residual Ethanol.
7. Place MinElute column in a clean 1.5 mL microcentrifuge tube.
8. Add 50 µL EB Buffer (10mM Tris-Cl, pH 8.5) or water directly onto center of the MinElute membrane. Incubate column for 1 minute at room temp, and then centrifuge column at 17,900 RCF for 1 minute.
9. Run 2 µL of purified DNA with 5 µL of diluted gel loading dye next to 2 µL pooled unpurified DNA with 5 µL gel loading dye on 0.8% agarose gel for 60 minutes at 100V to verify the purity of the DNA sample with no primer carry-over or contaminating gDNA.
10. This is your purified amplicon pool ready for Illumina sequencing.

Suggested Suppliers

Qiagen: MinElute® PCR Purification Kit (Cat. No. 28004)

Fisher Scientific: Biotech Grade Water BP24854

This document and its contents are proprietary to Shoreline Biome, LLC and are intended solely for the contractual use of its customer in connection with the use of the product(s) described herein and for no other purpose. This document and its contents shall not be used or distributed for any other purpose and/or otherwise communicated, disclosed, or reproduced in any way whatsoever without the prior written consent of Shoreline Biome. Shoreline Biome does not convey any license under its patent, trademark, copyright, or common-law rights nor similar rights of any third parties by this document.

The instructions in this document must be strictly and explicitly followed by qualified and properly trained personnel in order to ensure the proper and safe use of the product(s) described herein. All of the contents of this document must be fully read and understood prior to using such product(s).

FAILURE TO COMPLETELY READ AND EXPLICITLY FOLLOW ALL OF THE INSTRUCTIONS CONTAINED HEREIN MAY RESULT IN DAMAGE TO THE PRODUCT(S), INJURY TO PERSONS, INCLUDING TO USERS OR OTHERS, AND DAMAGE TO OTHER PROPERTY.

SHORELINE BIOME DOES NOT ASSUME ANY LIABILITY ARISING OUT OF THE IMPROPER USE OF THE PRODUCT(S) DESCRIBED HEREIN (INCLUDING PARTS THEREOF OR SOFTWARE) OR ANY USE OF SUCH PRODUCT(S) OUTSIDE THE SCOPE OF THE EXPRESS WRITTEN LICENSES OR PERMISSIONS GRANTED BY SHORELINE BIOME IN CONNECTION WITH CUSTOMER'S ACQUISITION OF SUCH PRODUCT(S).

All names, logos, and trademarks are the property of their respective owners.